



Address: 8 Manburgh Terrace,
 Darra 4076
Postal P.O. Box 3045
Address: Darra Qld. 4076
Phone: +61 (7) 3375 3199
Facsimile: +61 (7) 3375 3886
E-mail: info@luxurypaints.com.au
 Date Issued: 9 July, 2019
LP0001

SPEEDPREP 3 in 1 PRIMER SEALER UNDERCOAT

Product Line: 21

Product Code: 2101, 2102, 2104; 2110; 2115.

Australian Paint Approval Scheme: 0172, 0183

Description

Speedprep 3 in 1 Primer Sealer Undercoat is a water-based primer / sealer / undercoat designed to be used on interior and exterior timber, plasterboard, fibro, fibrous plaster, masonry, cement, etc.

Speedprep 3 in 1 Primer Sealer Undercoat can be recoated with either water-based or solvent-based paints. Drying and recoating times are 30 minutes and 2 hours respectively for water based systems under good drying conditions. It is suggested to allow 4 hours drying for top coating with solvent based coatings. Do not apply when temperature is below 12°C or when humidity is excessive.

Speedprep 3 in 1 Primer Sealer Undercoat can be tinted using Luxury Machine Colorants to a range of pastel colours

Spreading rate is approximately 10 square metres per litre depending on application (brush, roller or spray), weather conditions and the surface material. Speedprep 3 in 1 Primer Sealer Undercoat has no roller splatter or spray and is non-toxic and lead-free.

Typical Specifications

Surface	Preparation	System	Dry Film Thickness
Timber (New timber)	Remove any contaminants. Sand to smooth surface.	First Coat: Speedprep Sealer Primer Undercoat Top Coat: 2 coats Sunshield Topcoat (ext.) alternatively 2 coats Easi Clean Interior.	30 - 40µm 50 - 60µm 50 - 60µm
Timber (Weathered timber)	Remove any contaminants. Sand to smooth surface.	First Coat: Multipurpose Undercoat * Top Coat: 2 coats Sunshield Topcoat	30 - 40µm 50 - 60µm
Plasterboard	Fill joints. Remove sanding dust.	First Coat: Speedprep Sealer Primer Undercoat Top Coat: 2 coats Easi Clean Interior	30 - 40µm 50 - 60µm
Masonry, brick, concrete blockwork, fibre cement board	Remove any contaminants.	First Coat: Speedprep Sealer Primer Undercoat Top Coat: 2 coats Sunshield Topcoat	30 - 40µm 50 - 60µm

Please Note: On very old weathered timber that has been sanded back to a “new surface” the timber cells are largely empty and the addition of 120 mL of Pale Boiled Linseed Oil per 4 litres of Multi Purpose Undercoat is highly beneficial to help nourish the timber. Multipurpose Undercoat requires overnight dry before top coating.

Surface Preparation

All surfaces must be dry, well prepared and free from dirt, oil, grease and other contaminants.

New Plasterboard/Timber/Brick/Masonry

Fill any holes with suitable filler following the manufacturer’s directions. Sand surfaces smooth, remove all dust, grease and dirt. Apply one coat of Speedprep Sealer Primer Undercoat.



Address: 8 Manburgh Terrace,
Darra 4076
Postal P.O. Box 3045
Address: Darra Qld. 4076
Phone: +61 (7) 3375 3199
Facsimile: +61 (7) 3375 3886
E-mail: info@luxurypaints.com.au
Date Issued: 9 July, 2019
LP0001

Previously Painted Surfaces

Remove all loose and flaking paint with a wire brush or scraper. Ensure old paint has good adhesion to the substrate. Gloss enamel surfaces must be first sanded to a dull finish to obtain good inter-coat adhesion.

Application Method

Stir contents of can thoroughly with a wide flat stirrer ensuring the bottom of the can is reached. Apply 1 full coat of Speedprep 3 in 1 Primer Sealer Undercoat by brush, roller or spray.

Do not apply Speedprep 3 in 1 Primer Sealer Undercoat below 12°C or is likely to fall below 12°C before the paint can through dry.

Brush/Roller

Pre-wet brushes and rollers. Flow paint generously and spread evenly - do not overspread. Use a quality bristle brush or a medium 12mm-nap roller cover for best results. On rough surfaces, use a 20mm-nap roller cover. Avoid excessive brushing or rolling.

Spray

Suitable for application using standard spray equipment. If necessary, Speedprep 3 in 1 Primer Sealer Undercoat may be thinned sparingly with up to 100 mL of water per litre of paint to help atomization.

Thinning

Not usually required, however it may be thinned sparingly with water.

Approximate Coverage

Covers approximately 10 -12 square metres per litre depending on the surface porosity.

Colours Available

Available in white which may be tinted to pastel colours.

Drying Times

Approximate drying times at 25°C and 50% Relative Humidity.

Touch Dries: 30 minutes
Recoat: Minimum 2 hours.

Drying Times may be extended by adverse drying conditions or very high film build.

Cleanup

Clean all equipment promptly in water.

Properties

SOLIDS BY VOLUME: 36%
SOLIDS BY WEIGHT: 55%
WEIGHT PER LITRE: 1.4 Kg
GLOSS LEVEL: Low sheen
VOC: Approximately 24 grams per litre

Resistance Properties

ABRASION: N/A
HEAT: Up to 60°C
SOLVENT: Fair. Coating is a little sensitive to some solvents.
WATER/STEAM: Fair. Resists mild exposure to steam and condensation.
WEATHER: Interior/exterior use - excellent when top coated.



Address: 8 Manburgh Terrace,
Darra 4076

Postal P.O. Box 3045

Address: Darra Qld. 4076

Phone: +61 (7) 3375 3199

Facsimile: +61 (7) 3375 3886

E-mail: info@luxurypaints.com.au

Date Issued: 9 July, 2019

LP0001

Additional Information

To achieve a very smooth finish, lightly sand Speedprep 3 in 1 Primer Sealer Undercoat before top coating.

On very old exterior timber which has suffered from extensive degradation such as on old Queenslander type homes, it is recommended to use Multipurpose Undercoat mixed with a little pale boiled linseed oil to help nourish the timber.